

STEAM

Instant **hot** water dispenser




- מדריך למשתמש -


STEAM הוא מתקן נוח לשימוש ואמין במיוחד המפיק מים רותחים בטמפרטורה של 92-96 מעלות.
STEAM משתלב בטבעיות במטבח המודרני, מותקן תחת הכיור ומפנה מקום על השיש.
STEAM כולל ברז מזיגה במגוון צבעים מרהיבים למים פושרים או קרים ומים רותחים.

מבט כללי על המערכת

חזית המכשיר



גב המכשיר



תתחדשו!


אנו שמחים שבחרתם להצטרף למשפחת אקוואטק ולרכוש את Steam, מתקן המים החמים שהופך את המטבח לחוויה.
מהיום תהנו ממים חמים ללא הפסקה והרבה מקום פנוי על השיש.




הוראות התקנה

בדיקות לאחר התקנה ראשונית

1. מזוג 3 כוסות מים רותחים וודא פעולה תקינה של המערכת
2. וודא כי נורת החיווי פועלת בעת החימום



אופן התקנה מומלץ



1. יש לקרוא בעיון את הוראות ההתקנה ולפעול לפיהן.

יש לוודא הימצאות של כל האביזרים באריזה:

- מכשיר Steam
- צינור מזיגה
- צינור הזנה
- צינור ניקוז
- שקית ברגי התקנה (3)
- חבק ניקוז
- כבל הזנת חשמל
- מקדח 3 מ"מ

2. התקן את ברז המזיגה על השיש או הכיור

התקנת ה- Steam

3. הדבק את השרטוט המצורף במקום הנבחר
 - מומלץ להתקין את המכשיר בקו ישר עם הברז.
 - אורך הצינור בין המכשיר והברז לא יעלה על 40 ס"מ
4. קדח במקומות המסומנים בעזרת מקדח 3 מ"מ (מצורף)
5. קבע את המכשיר בעזרת הברגים המצורפים
6. חבר את צינור המזיגה לברז
7. חבר את צינור הניקוז אל הביוב בעזרת חבק הניקוז המצורף.
8. **אזהרה: את חבק הניקוז יש להתקין מעל הסיפון בלבד!**
9. חבר את צינור ההזנה אל מקור המים (מערכת RO)
10. מלא את המכשיר במים
11. מזוג 3 ליטר מים לשטיפת המערכת
11. **אזהרה: יש לחבר את המכשיר לחשמל רק לאחר מילוי במים ושטיפה!**
12. חבר את המכשיר אל החשמל, המכשיר יתחיל לחמם באופן אוטומטי

דגשים ואזהרות בטיחות

- חובה לחבר את המכשיר לאוסמזה הפוכה. במידה והמכשיר אינו מחובר לאוסמזה הפוכה, החברה לא תהיה אחראית לנזקי אבנית
- התקנת המכשיר תבוצע על ידי טכנאי שעבר הכשרה מתאימה בלבד
- המכשיר נועד לשימוש ביתי בלבד
- יש לחבר את המכשיר לשקע חשמל תקני מוארק, 230V, חד פאזי
- לחץ המים בכניסה לא יעלה על 2.5 בר
- נורית החיווי דולקת בעת הרתחת המים בלבד
- במידה והמערכת לא מוציאה מים, יש לבדוק את מקור ההזנה של המערכת
- אין לנקות את ברז המזיגה בעזרת חומרי ניקוי ואין לשפשף את הברז. ניקוי הברז יתבצע בעזרת מטלית לחה בלבד
- בעת היעדרות של 24 שעות ומעלה חובה לנתק את המכשיר מהחשמל
- יש להרחיק מהישג ידם של ילדים
- השימוש במים הרותחים באחריות ובפיקוח של מבוגר בלבד
- **אזהרה: יחידת החימום מחוברת למערכת הניקוז על מנת לסלק עודפי מים. בשום אופן אין לגעת ו/או לבטל חיבור זה.**
- השימוש במכשיר באחריות המשתמש בלבד.
- אחריות 12 חודשים

לפיתרון מושלם הוסיפו את Aquachill ותהנו ממים רותחים וקרים במזיגה קלה במיוחד!

Safety and warning notes

- The device must be connected to reverse osmosis. The company will not be responsible for limescale damage if the device is not connected to reverse osmosis.
- The installation of the device must be performed by a qualified technician with the appropriate training
- The device is intended for residential use only
- The device must be connected to a standard earthed single phase electrical outlet, 230V
- The inlet water pressure must not exceed 2.5 bar
- The indicator is lit only when the water is boiling
- If the system does not produce water, check the system's power source
- Do not clean the faucet with detergents and do not rub or scratch the faucet.
- Cleaning the faucet
- Clean the faucet only with a damp cloth.
- During an extended absence of 24H or more, the device must be disconnected from the power supply
- Keep out of the reach of children
- The use of hot water must be under the responsibility and supervision of an adult only
- **Warning: The heating unit is connected to the drainage system in order to remove excess water. Never touch and/or cancel this connection.**
- The use of the device is under the sole responsibility of the user.
- Warranty of 12 months

To create the perfect solution, add
Aquachill and enjoy hot and cold water
with an extremely easy pouring!

Installation Instructions

1. Read the installation instructions carefully and follow them

Ensure that all the accessories are supplied:

- Steam device
- Pouring pipe
- Inlet pipe
- Drain pipe
- Installation screws (3)
- Drain pipe clamp
- Power supply cable
- 3mm drill bit

2. Install the faucet on the countertop or the sink

Installing Steam

3. Place the attached drawing in the desired location.
 - It is recommended to install the device in a straight line with the faucet.
 - The length of the pipe between the device and the faucet shall not exceed 40 cm.
4. Drill in the marked location using the 3 mm drill (supplied).
5. Fix the device with the supplied screws.
6. Connect the pouring pipe to the faucet.
7. Connect the drain pipe to the drain Using the drain pipe clamp.

Warning: The drain hose clamp must be installed above the syphon only!


8. Connect the inlet pipe to the water supply (RO system).
9. Fill the device with water.
10. Pour 3 liters of tap water to flush the system.

11. Warning: The device must be connected to the power supply only after filling it with water and flushing the system!

12. Connect the device to the power supply.
13. The device will start heating automatically.

Inspection after initial installation

1. Pour 3 cups of hot water and ensure normal operation of the system
2. Ensure the indicator light is on during the heating process



Recommended Installation Diagram

Enjoy your new product!

We thank you for joining the Aquatech family and purchasing the **Steam Hot Water Dispenser.**


With Steam you will always have hassle-free hot water at your fingertips.
Never wait again for hot water.




STEAM is an easy-to-use and extremely reliable device that produces hot water at a temperature of 92-96°C
STEAM blends naturally into every modern kitchen. The device is installed under the sink and frees space on your kitchen countertop.
STEAM includes a faucet in a variety of spectacular colors for lukewarm, cold and hot water.

System Overview

Front



Back



STEAM

Instant **hot** water dispenser



- User Manual -